

EON7 185


QUICKSTART GUIDE

1. POWER ON THE UNIT

1. Connect the power cord to the **AC Power Connector (I)**.
2. Press the **Power Button (D)** for .5 second to engage power.


2. PLUG IN THE INPUTS

1. Turn the **Main Volume (E)** to the left until the LCD screen displays -100db before connecting inputs.
2. Connect your devices to the **Input Jacks (B) (G)**.
3. Turn **Main Volume (E)** until desired volume is reached.






3. PLACE IN DESIRED LISTENING POSITION



Main Speaker Position



Pole Mounted



4. JBL PRO CONNECT

1. The JBL Pro Connect app is a Bluetooth Low Energy control application used to remotely control the features within the EON 718s. The app is a free download on iOS and Android.
2. It is recommended that all users download the app and ensure their unit is operating on the latest firmware for the best experience.
3. Initiate BT Control pairing by pressing the MAIN/MENU knob and navigating to settings.
4. Your app will send a 4-digit PIN to your speaker. Confirm it on the LCD by pressing the MAIN/MENU knob.



Pour la version française de ce document, veuillez visiter le site www.jblpro.com/eon700

Die deutsche Version dieses Dokuments finden Sie unter www.jblpro.com/eon700

Para la versión en español de este documento, por favor visite www.jblpro.com/eon700

Para a versão em português deste documento, visite www.jblpro.com/eon700

Per la versione italiana di questo documento, visitare www.jblpro.com/eon700

이 문서의 한국어 버전은 www.jblpro.com/eon700 를 방문하십시오

有關本文檔的中文版，請訪問 www.jblpro.com/eon700

For complete documentation, visit

www.jblpro.com/eon700